

# SUNSTONE GRILLS IGNITER BOX WIRE ASSEMBLY


FOR GRILL MODELS SUN3BIR, SUN4BIR, & SUN5BIR

1. The IR-Impulse Igniter Wire, Item No. P-GIMwire-IR - Plugs into top or bottom Sockets of Igniter box, and extends to back of grill for IR-Burner

2. The Impulse Igniter Wire, Item No. P-GIMwire - Plugs into top or bottom Sockets of Igniter Box, and installs into face of Firebox for Right base Burner.


3. The Ignition Split Wire, Item No. P-Ignitor W-sp - Plugs into Prong A Position, the Long wire end extends to Valve 2, plugging into position 2A, and the Short End extends to Valve 1 and plugs into 1A of Electrode.

ELECTRODE SWITCH



P-Electrode

IR-IMPULSE IGNITER WIRE




P-GIMwire-IR

IMPULSE WIRE



P-GIMwire

IGNITION SPLIT WIRE




P-IgnitorW-sp

IR-IGNITER BOX



P-GIgnitor-IR



4. The Ignition Split Wire, Item No. P-Ignitor W-sp - Plugs into Prong A Position, the Long wire end extends to Valve 2, plugging into position 2A, and the Short End extends to Valve 1 and plugs into 1A of Electrode.

